

### Code table

Symbol	Codeword
0	00
1	0101
-1	0100
2	01110
-2	01101
3	01111
-3	01100
4	100100
-4	100011
5	100101
-5	100010
6	100110
-6	100001
7	100111
-7	100000
8	1011000
-8	1010111
9	1011001
-9	1010110
10	1011010
-10	1010101
11	1011011
-11	1010100
12	1011100
-12	1010011
13	1011101
-13	1010010
14	1011110
-14	1010001
15	1011111
-15	1010000
16	11010000
-16	11001111
17	11010001
-17	11001110
18	11010010
-18	11001101
19	11010011
-19	11001100
